


KEYSWITCH MCP ON IP MODULE



The N/O contacts from the key switch on the MCP connected as shown associated in series with the fire resistor.

The address of the I/P stage can be attributed as an input on the panel config tied to activation of an O/P group with the sounders for the lockdown added.

