

SYGNO-FI EXPANDER ELMDENE PSU WIRING DETAILS

Wiring details - Sygno-fi Expander (SYG-EM)/Elmdene STX (EN54-4) PSU

(The Expander has been configured to monitor both the PSU's Mains (EPS) and Battery fault (GEN) relay contacts and must be wired as below to avoid a fault condition being reported.

